

Gallerie Wrap Pro

(Professional Version)

Step-by-Step Instruction

Congratulations on the purchase of your superior solution for hanging artwork. **For the Gallerie Wrap Professional Version, you need the image to be 1,8"-2" (4,50 cm - 5,10 cm) bigger on each side** than your final frame size.


Please note: A Hahnemühle Gallerie Wrap Corner Kit is required to assemble this wrap.

- 

1) Peel the yellow adhesive strip from the bars. Insert the bars into the positioning corners with the adhesive facing up. Make sure the bars are flush with the positioning corner, and press firmly down inside the positioning corner. The positioning corners have tabs. The bars can only be inserted one way.
- 

2) Flip the frame over and center over artwork. Push bars down so they make contact with back of image. Afterwards remove the positioning corners.
- 

3) Trim the excess material around the edges of the stretcher bars.
- 

4) Run a small bead of pH neutral glue along the inside of the stretcher bars.
- 

5) Cut the corners outward where the bars meet at a 45 degree angle.
- 

6) Fold the corners onto the adhesive ends.
- 

7) Pull the bars up to close the frame. Insert staple into slots. Push or gently hammer staples flush with frame. Repeat on all corners.
- 

8) Insert four tensioners into the v-slots located in the frame corners. Insert centre brace if needed to stabilize the image (additionally available for Gallerie Wrap Professional).

